

Fuse accessory selection guide











	Fuse family	Size	PCB fuse clip	PCB mount holder	Panel mount	holder	In-line fuse	holder	Fuse block
	ABC AGC	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	HBH-I HBV-I	HTB HK HKP	HMR HGA HTJ	HRK HHB HFA HHK	HHN HFB HHJ	<u>S-4000</u> <u>S-8000</u>
-	AGA	1/4" x 5/8"	1Axxxx	-	-		-		-
4	<u>AGW</u>	1/4" x 7/8"	<u>1Axxxx</u>	-	-		HRK HHB		-
	AGX	1/4" x 1"	<u>1Axxxx</u>	-	HJL HJM		HRK HHB HHI		3828-1
	AHC(A) ADC	1/4" x 1 1/4" 6.3 mm x 32 mm	1Axxxx	HBH-I HBV-I	<u>HVP</u>		<u>HVI</u>		<u>S-8000</u>
© "902" © 005-989 © 055-989 © 055-989 ©	AMH & AML	55.4 mm x 17.7 mm x 12 mm	-	-	-		=		FMG BSCR101
0 0 0 0	AMX(L)	48 mm x 12 mm x 8.5 mm	-	-	-		-		<u>HMX</u>
	ATC	Auto Blade Fuse 19.1 mm x 18.7 mm	<u>1A5600</u>	-	-		<u>HHF-</u> <u>JFCU</u>		-
	ATM	Mini Blade Fuse 10.92 mm x 16.25 mm	<u>1A5778</u>	-	-		<u>HHM</u>		-
manue	<u>C519</u>	5 mm x 15 mm	<u>1Axxxx</u>	-	-		<u>HHT</u>		-
mum e	<u>C520</u>	5 mm x 15 mm	<u>1Axxxx</u>	-	-		<u>HHT</u>		-
20 Marie 100 Mar	FNM FNO	13/32" x 1 1/2" 10 mm x 38 mm	<u>1A3400</u>	-	<u>HP</u>		<u>HEB</u>		BMM603
	FNO-R KTK-R LP-CC	13/32" x 1 1/2" 10 mm x 38 mm	<u>1A3400</u>	-	<u>HP</u>		-		BCM603
SI YAU SISM	GBA GLD	1/4" x 1 1/4" 6.3 mm x 32 mm	<u>1Axxxx</u>	-	HLD		-		<u>S-4000</u> <u>S-8000</u>
	GBB	1/4" x 1 1/4" 6.3 mm x 32 mm	1Axxxx	HBH-I HBV-I	HTB HK HKP	HMR HGA HTJ	HRK HHB HFA HHK	HHN HFB HHJ	<u>S-4000</u> <u>S-8000</u>
Waste 1	GDA GDB GDC	5 mm x 20 mm	1Axxxx HTC-2xxM	<u>H15</u> HBH-M HBV-M	HTB HTC		<u>HHT</u>		HTC-15M HTC-5x8M HTC-78M
	GMA GMC GMD	5 mm x 20 mm	1Axxxx HTC-2xxM	<u>H15</u> HBH-M HBV-M	HTB HTC		<u>HHT</u>		HTC-15M HTC-5x8M HTC-78M
	KLKE KLM KTK	13/32" x 1 1/2" 10 mm x 38 mm	<u>1A3400</u>	-	<u>HP</u>		<u>HEB</u>		BMM603 EVMFH



	Fuse Family	Size	PCB Fuse Clip	PCB Mount Holder	Panel Mount Holder		In-Line Fuse Holder		Fuse Block
===	MDA MDL MDQ	1/4" x 1 1/4" 6.3 mm x 32 mm	1Axxxx	HBH-I HBV-I	HTB HK HKP	HMR HGA HTJ	HRK HHB HFA HHK	HHN HFB HHJ	<u>S-4000</u> <u>S-8000</u>
BUSS MON	MDH	1/4" x 1 1/4" 6.3 mm x 32 mm	1Axxxx	HBH-I HBV-I	HTB HK HKP	HMR HGA HTJ	HRK HHB HVI HHK	HHN HFB HHJ	<u>S-4000</u> <u>S-8000</u>
	<u>PCTron</u>	-	-	BK-PCS	-		-		-
***	<u>\$500</u> <u>\$501</u>	5 mm x 20 mm	1Axxxx HTC-2xxM	<u>H15</u> <u>HBH-M</u> <u>HBV-M</u>	<u>HTB</u>		<u>HHT</u>		<u>HTC-15M</u> <u>HTC-5x8M</u> <u>HTC-78M</u>
	<u>\$505</u> <u>\$506</u>	5 mm x 20 mm	1Axxxx HTC-2xxM	H15 HBH-M HBV-M	<u>HTB</u>		<u>HHT</u>		HTC-15M HTC-5x8M HTC-78M
三 明 市	<u>SC-xxA</u>	13/32" x various lengths 1.31" to 2.25"	1A3400	-	HPS-EE HPS-JJ HPS-FF		HEG HEH HEC HEJ		BG3011PQ
	SFE	1/4" x various lengths (5/8" to 1 7/16")	1Axxxx	-	-		HR/HM		-
	SR-5 / SR-5F / SR-5H SS-5 / SS-5F / SS-5H	-	-	BK-PCS	-		-		-
	<u>TDC10/11</u>	1/4" x 1 1/4" 6.3 mm x 32 mm	1Axxxx	HBH-I HBV-I	HTB HK HKP	HMR HGA HTJ	HRK HHB HFA HHK	HHN HFB HHJ	<u>S-4000</u> <u>S-8000</u>
Bussmann L	TDC180 TDC600	1/4" x 1"	1Axxxx	-	HJL HJM		HRK HHB HHI		3828-1

Tools & resources

- <u>Webpage</u>
- Parametric search tool
- How to select a fuse holder white paper

Eaton Electronics Division 1000 Eaton Boulevard Cleveland, OH 44122 United States www.eaton.com/electronics

© 2023 Eaton All Rights Reserved Printed in USA Publication No. 10575 BU-ELX22190 February 2023

