

Ordering Different Lead Types:

| | |
|----------------------|---------------------------------------|
| Inside Kinked Leads | Use -A after Ametherm's part # |
| Outside Kinked Leads | Use -B after Ametherm's part # |

For example: to order an inside kinked lead use part number SL15 5R008-A

